

QuickStop Parts & Install Instructions with Jackson Kayaks

Items are sent in two packages:

First Package includes:

1. QuickStop Anchor System – PowerPole Model
2. 4 Threaded Rods
3. 4 Knobs
4. Anchor Collar with eyelet bolt - installed on the end of the pole
5. Anchor Collar - installed on top to keep pole from going through anchor system if deployed in waters deeper than 7 ½'.
6. 1/8" Paracord Line

Second Package includes:

1. Anchor Pole:
 - a. 7 ½' long; ¾" diameter; 4lbs; solid fiber glass

QuickStop Anchor System Install Instructions:

1. Remove screws from the rear of the kayak
 - a. Screw size is ¼" by 20 thread
2. Install all 4 threaded rods – Install hex side up
 - a. The rods have a hex for easy removal if the rods get stuck
3. Insert anchor system on top of the threaded rods
 - a. The holes in the anchor system are elongated to fit inserts on kayak.

Insert system onto kayak over the threaded rods.

4. Install each knob on top of threaded rod – again, threaded rod is to be hex side up
 - a. Knobs are to be hand-tight

Pole Install Instructions:

1. Place anchor collar with ¾" screw to the top of the pole.
2. Insert the pole into the hole of the anchor system.
3. Place bottom anchor collar to the bottom of the pole.
 - a. Loosen eyelet to be able to place on the pole.
 - b. Once bottom anchor is on the pole and to the height you prefer, tighten eyelet in place.
4. Take the paracord and run through the block cheek piece on the side of anchor system.
5. Pull pole up and thread cord through the eyelet in a double knot.
 - a. Tip: You can attach cord to eyelet in advance.
6. You can now pull cord towards you to lift the pole up and release to lower the pole.

Please send any questions to YakGadgetHelp@gmail.com